

MZB 2600 coating device



- **High-quality stainless steel laboratory coating device**
- **Especially suitable for use in seed and seed production factories**
- **For wet coating of all common seed types such as maize and grain**
- **Combinable with the DRELO MZ 2000 automatic seed counting machines**

Count, fill and coat seeds

easily, fast, accurately with systems from

DRELO

www.drello.de

MZB 2600 coating device



Metering via a hose metering pump allows maximum repetition accuracy and leads to a distinct improvement of the coating quality compared to manual coating.

The integrated aspiration with exhaust air prevents pollution of the ambient air with coating dust or fumes.

The coating cycle is preset via 3 rotary knobs for pump running time, mixing time and discharge time. The set times appear in the display in seconds. The seeds are filled into the grain funnel.

After pressing the start button, the seeds are coated when the integrated mixing drum is rotated.

The coated seeds flow through a output channel into the attached bag.

Starting the coating cycle without an attached bag as well as double filling of the bag is prevented by the integrated bag detection system.

The coating device can be operated in conjunction with the MZ 2000 automatic seed counting machine from DRELO.

A set amount of grain is filled into the grain funnel of the coating device via the counting device.

The preset coating process starts automatically after the counting process is completed.

The operator must only replace the bags after filling.

The new counting process starts again during the coating process so that no waiting times occur.

Technical data

MZB 2600

Coating quantity	25 to 250 grains (medium-sized maize)
Coating cycle [s]	1.5 to 60
Electrical	
Supply voltage	85 - 264 V AC
Frequency	50 - 60 Hz
Power consumption	2.5 A
Power consumption	60 W
Ambient conditions	
Operating temperature	0 to +45 °C
Air humidity	≤ 80%, non-condensing
Overall dimensions	
Width (including storage container)	510 mm
Height	310 mm
Depth (without base plate)	180 mm
Depth (with base plate)	200 mm
Weight	approx.. 10.5 kg
Scope of supply	
MZB 2600 coating device	
Mordant bottle	
Silicon hose	
Aspiration hose	
Options in conjunction with the MZ 2000 automatic seed counting machines	
Control cable	
Mounting plate	
Options in conjunction with MZB 2600 coating device	
Control cable	
Mounting plate	

Count, fill and coat seeds

easily, fast, accurately with systems from

DRELO

www.drello.de